Audiovox 8910 Programming Instructions

- Turn the phone on. Newly unprogrammed phones for the first time should display "***Programming Required"*** on screen.
- Enter **[#] [#] [2] [0] [0] [2] [2] [0] [0] [2] [END]**. This will take you to the initial menu.
- Enter the **One Time subsidy Lock Code**.
- The following menu will appear:
    - ***Dir Number***
    - ***Phone Number***
    - ***Homesys ID***
- **Press (1)** to select **"Dir Number"** and enter the assigned **10-digit phone number**.
- Press **<STO>** to confirm entry. **<STO>** is the left Smart Key under the screen.
- To finish NAM programming press **<END>.**
- Phone will power cycle to complete the programming.

895 Don Mills Road
Two Morneau Sobeco, Suite 104
Don Mills, Ontario
M3C 1W3